



PlateWriter 3000 / NewsWriter Head Cap Maintenance

- 1) Power off printer
- 2) Enter service mode by pushing down the arrow right, arrow down, and enter button, then while holding down the buttons power on printer. Release buttons after it starts up.



- 3) Arrow right to Printer Setup
- 4) Arrow right to maintenance, scroll down to wiper exchange, then arrow right to sequence, then press enter.



- 5) Open the ink drier, and remove access panel, then clean the wiper blade, and pad.



- 6) With the ink drier open, power down the printer, then the pad will slide back and expose the head caps. Clean the head caps.



- 7) Close the ink drier, then power printer on. The print head will then move back to position, and you're done.