

# **PW2000 – Daily Operations Checklist**

1. Important! Always leave Mains power on at Printer whenever Liquid Dot is installed! This is so the printer can clean itself from time to time.
2. Important! Always leave Finishing Unit mains power ON whenever Gum is in the gum bottle. Note: Typically Mon-Fri or whenever the system in use and Gum is in the bottle it is recommended to leave the mains power ON and so that the system can jog every 30 minutes in order to help keep clean and prevent gum rollers from sticking together.
3. Before making plates each day take a quick look at control panel printer and make sure no error messages that require attention such as REPLACE CART # 1 etc. The display should normally indicate READY.
4. Before making plates each day make sure you have Gum in the gum bottle and it is fresh. If dark and discolored indicates it is getting too thick and old and should be replaced.
5. Important! Before feeding a plate through the Finishing Unit, make sure the Green LED is ON solid and not flashing. Flashing means system is busy and please wait!
6. Refer to and perform routine Preventive Maintenance Tasks as outlined in the document “GOLDEN RULES OF MAINTENANCE”.